
## **EXISTING TREE INVENTORY - SINGLE TREE**

No.	Botanical Name	Common Name	DBH (m)	CRZ (m)	Condition	Remarks	Recomm.	
						Old wound 0.2m above base rotted out.		
1	Acer x freemanii	Freeman Maple	1.40	14.00	F	Otherwise healthy. Multi-stem from	Remove	
						1.75m		
2	Sorbus spp	Mountain Ash	0.11	1.10	F	Multi-stem / Dieback / Thin canopy	Remove	
2	Acer negundo	Manitoba Maple	0.28	2.80	Р	Multi-stem / Multiple large wounds /	Remove	
3			0.28			Poor form		
4	Acer negundo	Manitoba Maple	0.31	3.10	Р	Multi-stem / One large stem alive but	Remove	
4			0.51			prostrate to ground / Poor form		
5	Acer negundo	Manitoba Maple	0.23	2.30	F		Remove	
6	Acer negundo	Manitoba Maple	0.57	5.70	F	Sweep / Moderate dieback	Remove	
7	Acer saccharum	Sugar Maple	0.58	5.80	G		Remove	
8	Acer saccharum	Sugar Maple	0.64	6.40	F	Wound at base / Internal rot	Remove	
9	Acer saccharum	Sugar Maple	0.86	8.60	VP	Severe internal rot / Barreling of stem	Remove	





Conflict trees to be removed

10-40cm Poor/Mostly dead Conflict trees to be removed

**EXISTING TREE INVENTORY - TREE GROUPING** 

Manitoba Maple

Glossy Buckthorn

Staghorn Sumac

10-30cm Good

5-10cm Good

5cm Good

5cm Good

Group Botanical Name

Acer negundo

Rhus typhina

Rhamnus cathartica



EXISTING TREE TO REMAIN


EXISTING TREE TO REMOVE

CRITICAL ROOT ZONE (CRZ)

TREE PROTECTION FENCE

The following protection measures must be implemented for retained trees, both on site and on adjacent sites, prior to any tree removal or site works and maintained for the duration of construction on site:

- 1. Under the guidance of a Landscape Architect or Certified Arborist, erect a fence at the critical root zone (CRZ) of trees where the CRZ is established as being 10 centimetres from the trunk of a tree for every centimetre of trunk diameter at breast height. The CRZ is calculated as DBH x 10cm. Refer to the Tree
- Protection Fence detail. See plan for fence location. 2. When trees to be removed overlap with the CRZ of trees to be preserved: cut roots at the edge of the CRZ and grind down stumps after tree removals, do not pull out stumps. Ensure there is not root pulling or disturbance of the ground within the CRZ.
- 3. If roots must be cut, roots 20mm or larger should be cut at right angles with clean, sharp horticultural tools without tearing, crushing, or pulling. Refer to City of Ottawa Specification S.P. F-8011 Tree
- Protection, Excavation of Root Zone. 4. Hand work only where required within the CRZ; absolutely no machinery permitted.
- 5. Do not place any material or equipment within the CRZ of any tree. 6. Do not attach any signs, notices or posters to any tree.
- 7. Do not disturb, raise or lower the existing grade within the CRZ without approval.
- 8. Only tunnel or bore when digging within the CRZ of a tree. 9. Do not damage the root system, trunk, or branches or any tree.
- 10. Ensure that exhaust fumes from all equipment are directed away from any tree canopy.



THE POSITION OF ALL POLE LINES, CONDUITS, WATERMAINS, SEWERS AND OTHER UNDERGROUND AND OVERGROUND UTILITIES AND STRUCTURES IS NOT NECESSARILY SHOWN ON THE CONTRACT DRAWINGS, AND WHERE SHOWN, THE ACCURACY OF THE POSITION OF SUCH UTILITIES AND STRUCTURES IS NOT GUARANTEED. BEFORE STARTING WORK, DETERMINE THE EXACT LOCATION OF ALL SUCH UTILITIES AND STRUCTURES AND ASSUME ALL LIABILITY FOR DAMAGE TO THEM.

NOT FOR CONSTRUCTION

				SCALE	DESIGN	
					RJ	
				1:200	CHECKED	
					RJ	
					DRAWN	
					MT	
				1;200	CHECKED	1
2.	ISSUED FOR SITE PLAN APPLICATION	DEC 15/17	RJ	0 2 4 6 8	RJ	
1.	ISSUED FOR COORDINATION	DEC 1/17	RJ		APPROVED	1
No.	REVISION	DATE	BY		RJ	



Suite 200, 240 Michael Cowpland Drive Ottawa, Ontario, Canada K2M 1P6 (613) 254-9643 (613) 254-5867 Facsimile

Website

www.novatech-eng.com

TREE PROTECTION

CITY of OTTAWA 3443 INNES ROAD

> DRAWING NAME TREE CONSERVATION PLAN

117077-00 REV # 2 RAWING No.

117077-TCR